# Service Manual Outline


**Section 1 - Important Information**
- A - General Information
- B - Maintenance
- C - Troubleshooting

**Section 2 - Removal and Installation**
- A - MCM Models

**Section 3 - Engine Mechanical**
- A - 4.3 liter (262 cid)

**Section 4 - Electrical System**
- A - Starting System
- B - Ignition System
- C - Charging System
- D - Wiring Diagrams

**Section 5 - Fuel System**
- A - Fuel Delivery System

**Section 6 - Cooling System**
- A - All Models
- B - Seawater Cooled Models
- C - Closed Cooled Models

**Section 7 - Exhaust System**
- A - Manifolds and Elbows

**Section 8 - Power Steering**
- A - Power Steering Pump

Important Information 1

Removal And Installation 2

Engine Mechanical 3

Electrical System 4

Fuel System 5

Cooling System 6

Exhaust System 7

Power Steering 8





APERÇU — Engine Manual — fichier complet disponible après achat 1/10

# Notice

Throughout this publication, Dangers, Warnings and Cautions (accompanied by the International HAZARD Symbol ⚠ ) are used to alert the mechanic to special instructions concerning a particular service or operation that may be hazardous if performed incorrectly or carelessly. **OBSERVE THEM CAREFULLY!**

These Safety Alerts alone cannot eliminate the hazards that they signal. Strict compliance to these special instructions when performing the service, plus Common Sense operation, are major accident prevention measures.

**⚠ DANGER**

**Immediate hazards which will result in severe personal injury or death.**

**⚠ WARNING**

**Hazards or unsafe practices which could result in severe personal injury or death.**

**⚠ CAUTION**

**Hazards or unsafe practices which could result in minor personal injury or product or property damage.**

# Notice to Users of This Manual

This service manual has been written and published by the Service Department of Mercury Marine to aid our dealers' mechanics and company service personnel when servicing the products described herein.

It is assumed that these personnel are familiar with marine product servicing procedures. Furthermore, it is assumed that they have been trained in the recommended service procedures of Mercury MerCruiser product, including the use of mechanics' common hand tools and the special Mercury Marine or recommended tools from other suppliers.

We could not possibly know of and advise the marine trade of all conceivable procedures and of the possible hazards and/or results of each method. Therefore, anyone who uses a service procedure and/or tool, which is not recommended by the manufacturer, first must completely satisfy himself that neither his nor the products safety will be endangered.

All information, illustrations and specifications contained in this manual are based on the latest product information available at the time of publication. As required, revisions to this manual will be sent to all dealers contracted by us to sell and/or service these products.

We reserve the right to make changes to this manual without prior notification.

Refer to dealer service bulletins, operation maintenance and warranty manuals and installation manuals for other pertinent information concerning the products described in this manual.



APERÇU — Engine Manual — fichier complet disponible après achat 2/10

## Precautions

It should be kept in mind, while working on the product, that the electrical system and ignition system are capable of violent and damaging short circuits or severe electrical shocks. When performing any work where electrical terminals could possibly be grounded or touched by the mechanic, the battery cables should be disconnected at the battery.

Any time the intake or exhaust openings are exposed during service they should be covered to protect against accidental entrance of foreign material which could enter the cylinders and cause extensive internal damage when the engine is started.

It is important to note, during any maintenance procedure replacement fasteners must have the same measurements and strength as those removed. Numbers on the heads of the metric bolts and on the surfaces of metric nuts indicate their strength. American bolts use radial lines for this purpose, while most American nuts do not have strength markings. Mismatched or incorrect fasteners can result in damage or malfunction, or possibly personal injury. Therefore, fasteners removed should be saved for reuse in the same locations whenever possible. Where the fasteners are not satisfactory for re-use, care should be taken to select a replacement that matches the original.

# Engine Mechanical Components

Many of the engine mechanical components are designed for marine applications. Unlike automotive engines, marine engines are subjected to extended periods of heavy load and wide open throttle operation and, therefore, require heavy-duty components. Special marine engine parts have design and manufacturing specifications that are required to provide long life and dependable performance. Marine engine parts also must be able to resist the corrosive action of salt or brackish water that will rust or corrode standard automotive parts within a short period of time.

Failure to use recommended Quicksilver service replacement parts can result in poor engine performance and/or durability, rapid corrosion of parts subjected to salt water and possibly complete failure of the engine.

# Replacement Parts

Use of parts other than the recommended service replacement parts, will void the warranty on those parts that are damaged as a result.

**⚠ WARNING**

**Electrical, ignition and fuel system components on Mercury MerCruiser Engines and Stern Drives are designed and manufactured to comply with U.S. Coast Guard Rules and Regulations to minimize risks of fire or explosion.**

**Use of replacement electrical, ignition or fuel system components, which do not comply to these rules and regulations, could result in a fire or explosion hazard and should be avoided.**

**When servicing the electrical, ignition and fuel systems, it is extremely important that all components are properly installed and tightened. If not, any electrical or ignition component opening would permit sparks to ignite fuel vapors from fuel system leaks, if they existed.**



APERÇU — Engine Manual — fichier complet disponible après achat 3/10

# Models Covered in This Manual

| Sterndrive (MCM) | Serial Number |
|---|---|
| 4.3L MPI Alpha and Bravo | 0M300000 and Above |



APERÇU — Engine Manual — fichier complet disponible après achat 

THIS PAGE IS INTENTIONALLY BLANK



APERÇU — Engine Manual — fichier complet disponible après achat 

# IMPORTANT INFORMATION

## Section 1A - General Information


Introduction . . . . . 1A-2
How to Use This Manual . . . . . 1A-2
Page Numbering . . . . . 1A-2
Engine Serial Number Locations . . . . . 1A-3
Mercury/Quicksilver Lubricants, Sealants And Adhesives . . . . . 1A-4


# IMPORTANT INFORMATION

## Section 1B - Maintenance


Torque Specifications . . . . . 1B-2
Special Tools . . . . . 1B-2
Lubricants / Sealants / Adhesives . . . . . 1B-3
Engine And Tune-Up Specifications . . . . 1B-4
MCM (Sterndrive) Models . . . . . 1B-4
Fluid Specifications . . . . . 1B-5
Engines . . . . . 1B-5
Sterndrives . . . . . 1B-5
Maintenance Schedules . . . . . 1B-6
Maintenance Intervals . . . . . 1B-6
Routine Maintenance . . . . . 1B-7
Scheduled Maintenance . . . . . 1B-8
Crankcase Oil . . . . . 1B-10
Overfilled Crankcase Oil . . . . . 1B-11
Checking . . . . . 1B-11
Filling . . . . . 1B-12
Changing Oil and Filter . . . . . 1B-13
Flushing The Power Package - MCM . . 1B-15
Sterndrive Water Pickups . . . . . 1B-15
Alternative Water Pickups . . . . . 1B-17
Sterndrive Unit Oil . . . . . 1B-19
Checking . . . . . 1B-19
Filling . . . . . 1B-19
Changing . . . . . 1B-20
Power Trim Pump Fluid . . . . . 1B-22
Checking . . . . . 1B-22
Filling . . . . . 1B-22
Changing . . . . . 1B-22
Power Steering Pump Fluid . . . . . 1B-23
Checking . . . . . 1B-23
Filling and Bleeding . . . . . 1B-24
Water Inlets . . . . . 1B-26
Seawater Strainer . . . . . 1B-26
Closed Cooling System . . . . . 1B-27
Checking Coolant Level . . . . . 1B-27
Cleaning and Inspection . . . . . 1B-27
Changing Coolant . . . . . 1B-27
Anodes . . . . . 1B-28
Propeller Shaft . . . . . 1B-31
Power Package Surfaces . . . . . 1B-32
Painting Your Power Package . . . . . 1B-32
Battery . . . . . 1B-33
Instruments . . . . . 1B-33
Gimbal Ring / Steering Connection . . . . 1B-33
Changing Water Separating Fuel Filter . 1B-34
Steering System . . . . . 1B-35
Remote Control . . . . . 1B-35
Sterndrive Components . . . . . 1B-35
Lubrication . . . . . 1B-35
Throttle Cable . . . . . 1B-35
Shift Cable . . . . . 1B-36
Sterndrive Components . . . . . 1B-36
Continuity Circuit . . . . . 1B-41
MerCathode . . . . . 1B-43
Engine Mounts . . . . . 1B-43
Electrical System . . . . . 1B-43
Cleaning Flame Arrestor . . . . . 1B-44
Serpentine Drive Belt . . . . . 1B-45
Sterndrive Models . . . . . 1B-45
Inspection . . . . . 1B-45
Replacing Belt and/or Adjusting Tension . . . . . 1B-46
Exhaust System . . . . . 1B-47
Seawater Pump . . . . . 1B-47
Cold Weather And Extended Storage . . 1B-48
Preparing Your Power Package For Storage . . . . . 1B-48
Draining Instructions . . . . . 1B-50
Identification . . . . . 1B-51
Boat In The Water . . . . . 1B-52
Boat Out Of The Water . . . . . 1B-56
All Models . . . . . 1B-59





APERÇU — Engine Manual — fichier complet disponible après achat 6/10

# IMPORTANT INFORMATION

## Section 1C - Troubleshooting


Used Spark Plug Analysis . . . . . 1C-2
Normal Condition . . . . . 1C-2
Chipped Insulator . . . . . 1C-3
Wet Fouling (Oil Deposits) . . . . . 1C-3
Cold Fouling . . . . . 1C-4
Overheating . . . . . 1C-4
High Speed Glazing . . . . . 1C-5
Scavenger Deposits . . . . . 1C-5
Pre-Ignition Damage . . . . . 1C-6
Reversed Coil Polarity . . . . . 1C-6
Splashed Deposits . . . . . 1C-7
Mechanical Damage . . . . . 1C-7
Poor Boat Performance And/Or Poor Maneuverability . . . . . 1C-8
Improper Full Throttle Engine RPM . . . . 1C-10
Engine Cranks Over But Will Not Start Or Starts Hard . . . . . 1C-11
Important Information . . . . . 1C-11
Engine Will Not Crank Over . . . . . 1C-12
Charging System Inoperative . . . . . 1C-12
Noisy Alternator . . . . . 1C-13
Instrumentation Malfunction . . . . . 1C-13
Radio Noise . . . . . 1C-13
Poor Fuel Economy . . . . . 1C-14
Engine Runs Poorly at Idle . . . . . 1C-15
Engine Runs Poorly At High RPM . . . . . 1C-16
Engine Acceleration Is Poor . . . . . 1C-17
Troubleshooting with Vacuum Gauge . . 1C-17
Engine Noise . . . . . 1C-18
Important Information . . . . . 1C-18
Oil Pressure . . . . . 1C-24
Excessive Oil Consumption . . . . . 1C-27
Water In The Engine . . . . . 1C-28
Important Information . . . . . 1C-28
Engine Overheats (Mechanical) . . . . . 1C-30
Power Steering . . . . . 1C-33
Drain System Will Not Drain Or Drains Slowly . . . . . 1C-35


# REMOVAL AND INSTALLATION

## Section 2A - MCM Models


Torque Specifications . . . . . 2A-2
Lubricants / Sealants / Adhesives . . . . . 2A-3
Special Tools . . . . . 2A-4
Removal . . . . . 2A-5
Engine Installation . . . . . 2A-8
Electrical Connections . . . . . 2A-13
EFI Electrical System Precautions . . 2A-13
Installing Continuity Wire . . . . . 2A-14
Instrumentation Connections . . . . . 2A-14
Trim Position Sender Connections . . 2A-15
MerCathode Connections . . . . . 2A-16
Audio Warning Alarm Connections . . 2A-17
Power Trim Pump Connections . . . . . 2A-17
Fluid Connections . . . . . 2A-18
Fuel . . . . . 2A-18
Gear Lube Monitor Hose . . . . . 2A-19
Power Steering Hoses . . . . . 2A-20
Bravo Models and Alpha Seawater Cooled Models Using Sterndrive Water Pickups . . . . 2A-21
Alpha or Bravo Models Using Alternative Water Pickups . . . 2A-21
Coolant Recovery Bottle . . . . . 2A-24
Shift Cable Installation . . . . . 2A-25
Alpha Models - Drive Unit Not Installed . . . . . 2A-25
Bravo Models . . . . . 2A-30
Throttle Cable Installation and Adjustment . . . . . 2A-35
Battery Connection . . . . . 2A-37
Engine Cover Installation . . . . . 2A-37





APERÇU — Engine Manual — fichier complet disponible après achat 7/10

# ENGINE MECHANICAL

## Section 3A - 4.3 liter (262 cid)


Identification . . . . . 3A-3
General Specifications . . . . . 3A-4
4.3 liter (262 cid) . . . . . 3A-4
Engine Specifications - 4.3 liter (262 cid) 3A-5
Cylinder Head . . . . . 3A-5
Cylinder Bore . . . . . 3A-5
Oil Pump . . . . . 3A-5
Piston Bore Clearance . . . . . 3A-5
Piston Rings . . . . . 3A-6
Piston Pin . . . . . 3A-6
Crankshaft . . . . . 3A-7
Connecting Rod . . . . . 3A-8
Valve . . . . . 3A-8
Valve (continued) . . . . . 3A-9
Camshaft . . . . . 3A-10
Timing Chain . . . . . 3A-10
Flywheel . . . . . 3A-10
Torque Specifications . . . . . 3A-11
Special Tools . . . . . 3A-15
Lubricants / Sealants / Adhesives . . . . . 3A-16
Precautions . . . . . 3A-18
General Information . . . . . 3A-19
Repair Procedures . . . . . 3A-19
Special Notice . . . . . 3A-19
Engine Rotation . . . . . 3A-19
Crankcase Oil Dipstick Measurements 3A-20
Engine Mounts . . . . . 3A-21
Exploded Views . . . . . 3A-21
Valve Cover . . . . . 3A-22
Removal . . . . . 3A-22
Cleaning and Inspection . . . . . 3A-22
Installation . . . . . 3A-23
Rocker Arm / Valve Pushrod . . . . . 3A-24
Removal . . . . . 3A-24
Cleaning . . . . . 3A-25
Inspection . . . . . 3A-25
Installation . . . . . 3A-26
Valve Stem Oil Seal / Valve Spring - Cylinder Head Installed . . . . . 3A-28
Exploded View . . . . . 3A-28
Removal . . . . . 3A-29
Installation . . . . . 3A-30
Intake Manifold Assembly . . . . . 3A-33
Exploded View . . . . . 3A-33
Removal . . . . . 3A-34
Cleaning . . . . . 3A-35
Inspection . . . . . 3A-35
Upper And Lower Intake Manifolds . . 3A-36
Installation . . . . . 3A-36
Hydraulic Valve Lifters . . . . . 3A-39
Exploded View . . . . . 3A-39
Special Information . . . . . 3A-39
Removal . . . . . 3A-40
Cleaning . . . . . 3A-41
Inspection . . . . . 3A-41
Installation . . . . . 3A-42
Camshaft and Camshaft Bearings . . . . . 3A-43
Measuring Camshaft Lobe Lift . . . . . 3A-43
Removal . . . . . 3A-45
Cleaning . . . . . 3A-49
Inspection . . . . . 3A-50
Installation . . . . . 3A-51
Cylinder Head . . . . . 3A-58
Removal . . . . . 3A-58
Disassembly . . . . . 3A-59
Cleaning . . . . . 3A-60
Inspection . . . . . 3A-61
Repair . . . . . 3A-66
Reassembly . . . . . 3A-69
Installation . . . . . 3A-73
Oil Pan . . . . . 3A-75
Removal . . . . . 3A-75
Cleaning . . . . . 3A-76
Inspection . . . . . 3A-76
Installation . . . . . 3A-76
Oil Pump . . . . . 3A-78
Exploded View . . . . . 3A-78
Removal . . . . . 3A-79
Disassembly . . . . . 3A-79
Cleaning . . . . . 3A-80
Inspection . . . . . 3A-81
Reassembly . . . . . 3A-82
Installation . . . . . 3A-84
Crankshaft Balancer . . . . . 3A-85
Removal . . . . . 3A-85
Cleaning . . . . . 3A-85
Inspection . . . . . 3A-85
Installation . . . . . 3A-86
Front Cover Oil Seal . . . . . 3A-88
Oil Seal Replacement Without Removing Front Cover . . . . 3A-88
Front Cover . . . . . 3A-89
Removal . . . . . 3A-89
Cleaning and Inspection . . . . . 3A-90
Installation . . . . . 3A-90





APERÇU — Engine Manual — fichier complet disponible après achat 8/10

Connecting Rod, Bearings and Piston Assembly . . . . . 3A-92
Exploded View . . . . . 3A-92
Removal . . . . . 3A-93
Disassembly . . . . . 3A-95
Cleaning . . . . . 3A-95
Inspection . . . . . 3A-96
Reassembly . . . . . 3A-111
Installation . . . . . 3A-114
Crankshaft, Main Bearings and Engine Block . . . . . 3A-118
Exploded View . . . . . 3A-118
Removal . . . . . 3A-119
Cleaning . . . . . 3A-123
Inspection . . . . . 3A-125
Installation . . . . . 3A-137
Timing Chain And Sprockets . . . . . 3A-147
Removal . . . . . 3A-147
Cleaning . . . . . 3A-148
Inspection . . . . . 3A-148
Reassembly . . . . . 3A-148
Installation . . . . . 3A-150
Flywheel Housing . . . . . 3A-151
Removal . . . . . 3A-151
Cleaning . . . . . 3A-152
Inspection . . . . . 3A-152
Installation . . . . . 3A-152
Flywheel . . . . . 3A-153
Removal . . . . . 3A-153
Cleaning and Inspection . . . . . 3A-154
Installation . . . . . 3A-154
Rear Oil Seal . . . . . 3A-156
Removal . . . . . 3A-156
Cleaning . . . . . 3A-156
Inspection . . . . . 3A-156
Installation . . . . . 3A-157
Rear Oil Seal Retainer . . . . . 3A-159
Removal . . . . . 3A-159
Cleaning . . . . . 3A-159
Inspection . . . . . 3A-159
Installation . . . . . 3A-160
Oil Filter By-Pass Valve and Block Adapter . . . . . 3A-161
Exploded View . . . . . 3A-161
Removal . . . . . 3A-162
Cleaning . . . . . 3A-163
Inspection . . . . . 3A-163
Installation . . . . . 3A-164




APERÇU — Engine Manual — fichier complet disponible après achat 9/10

# ELECTRICAL SYSTEM

## Section 4A - Starting System


Identification . . . . . 4A-2
Replacement Parts Warning . . . . . 4A-2
Precautions . . . . . 4A-2
Typical Starting System Components . . 4A-3
Positive Current Flow . . . . . 4A-4
Battery . . . . . 4A-4
  Battery Cable Recommendations . . . 4A-4
Delco PG260F1 Starter . . . . . 4A-5
Specifications . . . . . 4A-5
  Starter Specifications . . . . . 4A-5
  Torque Specifications . . . . . 4A-5
Lubricants / Sealants / Adhesives . . . . . 4A-5
Description . . . . . 4A-5
  Testing . . . . . 4A-6
Removal . . . . . 4A-8
  Solenoid Switch . . . . . 4A-9
Inspection . . . . . 4A-9
Installation . . . . . 4A-10


# ELECTRICAL SYSTEM

## Section 4B - Ignition System


Specifications . . . . . 4B-2
  Spark Plugs . . . . . 4B-2
  Distributor . . . . . 4B-2
  Coil . . . . . 4B-2
  Firing Order . . . . . 4B-2
Torque Specifications . . . . . 4B-2
Lubricants / Sealants / Adhesives . . . . . 4B-3
Spark Plugs . . . . . 4B-3
  Removal . . . . . 4B-3
  Inspection . . . . . 4B-3
  Replacing . . . . . 4B-4
Spark Plug Wires . . . . . 4B-5
  Inspection . . . . . 4B-5
  Replacing . . . . . 4B-5
Ignition Coil . . . . . 4B-7
  Removal . . . . . 4B-7
  Installation . . . . . 4B-8
Distributor . . . . . 4B-9
  Removal . . . . . 4B-9
  Disassembly . . . . . 4B-10
  Cleaning and Inspection . . . . . 4B-12
  Reassembly . . . . . 4B-12
  Installation . . . . . 4B-13


# ELECTRICAL SYSTEM

## Section 4C - Charging System


Delco Alternator . . . . . 4C-2
  Identification . . . . . 4C-2
  Replacement Parts Warning . . . . . 4C-2
  Specifications . . . . . 4C-3
  Torque Specifications . . . . . 4C-3
  Special Tools . . . . . 4C-3
Precautions . . . . . 4C-4
  EFI Electrical System Precautions . . 4C-4
Charging System Components . . . . . 4C-5
Periodic Maintenance . . . . . 4C-5
Troubleshooting Tests
 (Alternator on Engine) . . . . . 4C-5
  Charging System . . . . . 4C-6
  Resistance . . . . . 4C-7
  Circuitry . . . . . 4C-9
Removal . . . . . 4C-11
  Alternator . . . . . 4C-11
  Alternator Bracket . . . . . 4C-11
Installation . . . . . 4C-12
  Alternator Bracket . . . . . 4C-12
  Alternator . . . . . 4C-12
  Battery Isolator Diagram . . . . . 4C-14





APERÇU — Engine Manual — fichier complet disponible après achat 10/10