Service Manual Supplement Outline

Section 1 - Important Information
- A - General Information
- B - Maintenance

Section 3 - Engine
- A - 377 CID / 6.2L Engines

Section 4 - Electrical Systems
- E - Wiring Diagrams

Section 5 - Fuel Systems
- E - Fuel Injection System Assembly and Disassembly
- G - Diagnostics

APERÇU — Engine Manual — fichier complet disponible après achat 1/10

Notice

Throughout this publication, “Dangers,” “Warnings” and “Cautions” (accompanied by the International HAZARD Symbol ⚠) are used to alert the mechanic to special instructions concerning a particular service or operation that may be hazardous if performed incorrectly or carelessly. **OBSERVE THEM CAREFULLY!**

These “Safety Alerts” alone cannot eliminate the hazards that they signal. Strict compliance to these special instructions when performing the service, plus “Common Sense” operation, are major accident prevention measures.

⚠ DANGER

DANGER - Immediate hazards which WILL result in severe personal injury or death.

⚠ WARNING

WARNING - Hazards or unsafe practices which COULD result in severe personal injury or death.

⚠ CAUTION

Hazards or unsafe practices which could result in minor personal injury or product or property damage.

Notice to Users of This Manual

This service manual has been written and published by the Service Department of Mercury Marine to aid our dealers’ mechanics and company service personnel when servicing the products described herein.

It is assumed that these personnel are familiar with the servicing procedures of these products, or like or similar products manufactured and marketed by Mercury Marine, that they have been trained in the recommended servicing procedures of these products which includes the use of mechanics’ common hand tools and the special Mercury Marine or recommended tools from other suppliers.

We could not possibly know of and advise the service trade of all conceivable procedures by which a service might be performed and of the possible hazards and/or results of each method. We have not undertaken any such wide evaluation. Therefore, anyone who uses a service procedure and/or tool, which is not recommended by the manufacturer, first must completely satisfy himself that neither his nor the products safety will be endangered by the service procedure selected.

All information, illustrations and specifications contained in this manual are based on the latest product information available at the time of publication. As required, revisions to this manual will be sent to all dealers contracted by us to sell and/or service these products.

It should be kept in mind, while working on the product, that the electrical system and ignition system are capable of violent and damaging short circuits or severe electrical shocks. When performing any work where electrical terminals could possibly be grounded or touched by the mechanic, the battery cables should be disconnected at the battery.

Any time the intake or exhaust openings are exposed during service they should be covered to protect against accidental entrance of foreign material which could enter the cylinders and cause extensive internal damage when the engine is started.

APERÇU — Engine Manual — fichier complet disponible après achat 2/10

It is important to note, during any maintenance procedure replacement fasteners must have the same measurements and strength as those removed. Numbers on the heads of the metric bolts and on the surfaces of metric nuts indicate their strength. American bolts use radial lines for this purpose, while most American nuts do not have strength markings. Mismatched or incorrect fasteners can result in damage or malfunction, or possibly personal injury. Therefore, fasteners removed should be saved for reuse in the same locations whenever possible. Where the fasteners are not satisfactory for re-use, care should be taken to select a replacement that matches the original.

We reserve the right to make changes to this manual without prior notification.

Refer to dealer service bulletins for other pertinent information concerning the products described in this manual.

Engine Mechanical Components

Many of the engine mechanical components are designed for marine applications. Unlike automotive engines, marine engines are subjected to extended periods of heavy load and wide-open-throttle operation and, therefore, require heavy-duty components. Special marine engine parts have design and manufacturing specifications which are required to provide long life and dependable performance. Marine engine parts also must be able to resist the corrosive action of salt or brackish water that will rust or corrode standard automotive parts within a short period of time.

Failure to use recommended Quicksilver service replacement parts can result in poor engine performance and/or durability, rapid corrosion of parts subjected to salt water and possibly complete failure of the engine.

Use of parts other than recommended service replacement parts, will void the warranty on those parts which are damaged as a result of the use of other than recommended replacement parts.

Replacement Parts

⚠ WARNING

Electrical, ignition and fuel system components on MerCruiser Engines and Sterndrives are designed and manufactured to comply with U.S. Coast Guard Rules and Regulations to minimize risks of fire or explosion.

Use of replacement electrical, ignition or fuel system components, which do not comply to these rules and regulations, could result in a fire or explosion hazard and should be avoided.

When servicing the electrical, ignition and fuel systems, it is extremely important that all components are properly installed and tightened. If not, any electrical or ignition component opening would permit sparks to ignite fuel vapors from fuel system leaks, if they existed.

APERÇU — Engine Manual — fichier complet disponible après achat 3/10

Models Covered In This Manual

Sterndrive (MCM) Model	Serial Number
MX 6.2 MPI	0L680003 and Above

Inboard (MIE) Model	Serial Number
MX 6.2 MPI	0L680003 and Above

Ski Model	Serial Number
MX 6.2 Black Scorpion	0L680003 and Above

APERÇU — Engine Manual — fichier complet disponible après achat 4/10

Table of Contents

IMPORTANT INFORMATION

Section 1A - General Information

General Information 1A-3

Section 1B - Maintenance

Tools 1B-2
Lubricants / Sealants / Adhesives 1B-2
Maintenance Schedules 1B-3
  Maintenance Intervals 1B-3
Gas Sterndrive 1B-3
  Routine Maintenance * 1B-3
  Scheduled Maintenance * 1B-4
Gas Inboard 1B-5
  Routine Maintenance * 1B-5
  Scheduled Maintenance * 1B-6
Engine and Tune-Up Specifications 1B-7
  MCM (Sterndrive) 1B-7
  MIE (Inboard) 1B-8
  Ski 1B-9
Fluid Capacities 1B-10
  Engines 1B-10
  Sterndrives 1B-10
  Transmissions 1B-11
20-Hour Break-In Period 1B-11
After Break-in Period 1B-12
End of First Season Checkup 1B-12
Specifications 1B-12
  Fuel Recommendations 1B-12
  Test For Alcohol Content In Gasoline . 1B-15
Transmission Fluid 1B-15
Power Steering Fluid 1B-15
Coolant for Closed Cooling System 1B-15
Crankcase Oil 1B-16
  Overfilled Crankcase Oil 1B-16
  Checking Engine Oil Level / Filling ... 1B-17
Changing Oil and Filter 1B-17
Changing Water Separating Fuel Filter .. 1B-18
  MCM (Sterndrive) Models 1B-19
Power Steering System 1B-20
  Checking Fluid Level 1B-20
  Engine Cold 1B-20
  Filling and Bleeding 1B-21
Closed Cooling System 1B-22
  Checking Coolant Level 1B-22
  Flushing System MCM (Sterndrive) .. 1B-23
  Flushing System MIE
  (Inboard and Ski) 1B-25
Transmission Fluid 1B-26
Lubrication 1B-27
  Throttle Cable 1B-27
  Shift Cable and Transmission Linkage 1B-27
  Engine Coupler/U-Joint Shaft Splines 1B-29
  Sterndrive Drive Shaft Extension
  Models 1B-30
  Starter Motor 1B-30
Cleaning Flame Arrestor 1B-31
  Black Scorpion Flame Arrestor 1B-32
Serpentine Drive Belt 1B-32
  Component Location 1B-32
  Inspection 1B-34
  Replacing and/or Adjusting Tension .. 1B-34
Ignition Timing 1B-35
  EFI/MPI Models 1B-35
Cold Weather or Extended Storage 1B-36
  Precautions 1B-36
  Power Package Layup 1B-37
  Draining Instructions 1B-39
  Draining Sterndrive Unit 1B-43
  Recommissioning 1B-44

APERÇU — Engine Manual — fichier complet disponible après achat 5/10

ENGINE

Section 3A - 377 cid (6.2L) Engines

Torque Specifications 3A-3
Special Tools 3A-5
Specifications 3A-6
General Specifications 3A-6
Engine Specifications 3A-7
General Information 3A-11
Repair Procedures 3A-11
Engine Identification 3A-11
Engine Rotation 3A-12
Description 3A-12
Crankshaft 3A-12
Piston and Connecting Rods 3A-12
Camshaft and Drive 3A-12
Cylinder Head 3A-13
Valve Train 3A-13
Intake Manifold 3A-13
Lubrication System 3A-13
Bearing Failures 3A-14
Piston Failures 3A-16
Pre-Ignition 3A-16
Detonation 3A-17
Engine Mounts 3A-18
Engine Mounts (Continued) 3A-19
Rocker Arm Cover 3A-20
Removal 3A-20
Installation 3A-20
Intake Manifold 3A-21
Removal 3A-21
Cleaning and Inspection 3A-21
Installation 3A-22
Rocker Arm / Push Rod 3A-23
Removal 3A-23
Cleaning and Inspection 3A-23
Installation 3A-23
Valve Adjustment 3A-24
Engine Stopped 3A-24
Engine Operating 3A-25
Hydraulic Valve Lifters 3A-26
Locating Noisy Lifters 3A-26
Removal 3A-27
Cleaning and Inspection 3A-28
Installation 3A-28
Valve Stem Oil Seal / Valve Spring 3A-29
Removal - Head Installed 3A-29
Valve Assembly (Exploded View) 3A-30
Installation - Head Installed 3A-30
Cylinder Head 3A-31
Removal 3A-31
Cleaning and Inspection 3A-32
Installation 3A-32
Cylinder Head and Valve Conditioning . . 3A-33
Disassembly 3A-33
Cleaning and Inspection 3A-34
Valve Guide Bore Repair 3A-36
Valve Springs - Checking Tension 3A-36
Rocker Arm Stud Replacement 3A-37
Valve Seat Repair 3A-38
Valve Grinding 3A-39
Reassembly 3A-40
Crankcase Oil Dipstick Specifications . . . 3A-43
Oil Pan 3A-44
Removal 3A-44
Cleaning and Inspection 3A-44
Installation 3A-44
Oil Pump 3A-47
Exploded View 3A-47
Removal 3A-48
Disassembly 3A-49
Cleaning and Inspection 3A-49
Reassembly 3A-49
Installation 3A-50
Torsional Damper 3A-50
Removal 3A-50
Installation 3A-51
Crankcase Front Cover Oil Seal 3A-52
Oil Seal Replacement
(Without Removing Front Cover) 3A-52
Crankcase Front Cover 3A-53
Removal 3A-53
Cleaning and Inspection 3A-53
Installation 3A-53
Flywheel 3A-55
Removal 3A-55
Cleaning and Inspection 3A-55
Installation 3A-56
Rear Main Oil Seal 3A-57
Removal 3A-57
Cleaning and Inspection 3A-57
Installation 3A-57
Rear Main Oil Seal Retainer 3A-59
Removal 3A-59
Cleaning and Inspection 3A-59
Installation 3A-59
Main Bearings 3A-60
Inspection 3A-60
Checking Clearances 3A-60
Replacement 3A-62
Connecting Rod Bearings 3A-64
Inspection and Replacement 3A-64

APERÇU — Engine Manual — fichier complet disponible après achat 6/10

Section 3A - 377 cid (6.2L) Engines (Continued)

Connecting Rod / Piston Assembly 3A-66
Removal 3A-66
Disassembly 3A-67
Cleaning and Inspection 3A-68
Reassembly 3A-69
Installation 3A-71
Crankshaft 3A-73
Removal 3A-73
Cleaning and Inspection 3A-76
Installation 3A-76
Timing Chain and Sprocket 3A-77
Removal 3A-77
Cleaning and Inspection 3A-78
Crankshaft Sprocket/Gear 3A-78
Removal 3A-78
Installation 3A-78
Checking Timing Chain Deflection ... 3A-79
Camshaft 3A-79
Measuring Lobe Lift 3A-79
Removal 3A-80
Inspection 3A-80
Installation 3A-81
Camshaft Bearings 3A-81
Removal 3A-81
Cleaning and Inspection 3A-82
Installation 3A-82
Cylinder Block 3A-83
Cleaning and Inspection 3A-83
Oil Filter By-Pass Valve and Adaptor Assembly 3A-87
Removal 3A-88
Cleaning and Inspection 3A-88
Installation 3A-88

Section 4E - Wiring Diagrams

Starting and Charging Harness 4E-2
MCM MX 6.2L MPI Engines 4E-2
MIE MX 6.2 MPI and MX 6.2 Black Scorpion Engines - 4E-4
Fuel and Ignition System Harness 4E-6
MX 6.2 MPI and MX 6.2 Black Scorpion Engines 4E-6

FUEL SYSTEM

Section 5E - Fuel Injection Disassembly And Reassembly

Service Precautions 5E-2
Specifications 5E-3
Torque Specifications 5E-3
Lubricants / Sealants / Adhesives 5E-3
Sensor Voltage 5E-3
Exploded Views - MX 6.2L MPI 5E-4
Flame Arrestor And Throttle Body 5E-4
Intake Manifold And Fuel Rail 5E-5
Fuel Pressure Relief Procedure 5E-6
MX 6.2 MPI Components 5E-6
Flame Arrestor 5E-6
Throttle Body 5E-8
Throttle Position Sensor 5E-11
Idle Air Control (IAC) Valve 5E-13
Knock Sensor 5E-15
Knock Sensor Module 5E-16
Fuel Pump Relay 5E-16
System Relay 5E-17
Electronic Control Module (ECM) 5E-17
Engine Coolant Temperature (ECT) Sensor 5E-18
Vacuum And Vent Hose Routing 5E-19
MX 6.2 MPI Models 5E-19
Exploded Views - MX 6.2 Black Scorpion Plenum, Throttle Body And Flame Arrestor 5E-20
Intake Manifold And Fuel Rails 5E-21
Fuel Pressure Relief Procedure 5E-22
MX 6.2 Black Scorpion Components 5E-22
Flame Arrestor 5E-22
Throttle Body 5E-24
Plenum 5E-28
Fuel Rails 5E-30
Fuel Injectors 5E-32
MAP Sensor 5E-33
Throttle Position Sensor 5E-34
Idle Air Control (IAC) Valve 5E-35
Knock Sensor 5E-37
Knock Sensor Module 5E-38
Fuel Pump Relay 5E-39
System Relay 5E-39
Engine Control Module 5E-40
Engine Coolant Temperature Sensor . 5E-41
Vacuum And Vent Hose Routing 5E-42
MX 6.2 Black Scorpion Models 5E-42

APERÇU — Engine Manual — fichier complet disponible après achat 7/10

Section 5G - Diagnostics

Special Tools 5G-2
Special Tools (cont'd) 5G-3
Diagnostic Circuit Check 5G-4
Scan Tool Normal Specifications (Idle/Warm Engine/Closed Throttle/Neutral) 5G-4
Diagnostic Trouble Codes 5G-5
ECM Connector and EFI Symptoms Chart 5G-6
J-1 Circuits 5G-7
J-1 Circuits (Continued) 5G-8
J-2 Circuits 5G-9
J-2 Circuits(Continued) 5G-10
Wiring System Diagrams 5G-11
(Continued) 5G-12
With Mercury Distributor 5G-13
With GM EST Distributor 5G-14

APERÇU — Engine Manual — fichier complet disponible après achat 8/10

IMPORTANT INFORMATION

Section 1A - General Information

1 A

Table of Contents

General Information 1A-3

APERÇU — Engine Manual — fichier complet disponible après achat 9/10

THIS PAGE IS INTENTIONALLY BLANK

APERÇU — Engine Manual — fichier complet disponible après achat