Service Manual Outline

Section 1 - Important Information
- A - General Information
- B - Maintenance
- C - Troubleshooting

Section 2 - Removal and Installation
- A - Sterndrive (MCM) Models
- B - Inboard (MIE) Models

Section 3 - Engine Mechanical
- A - D2.8L D-Tronic And D4.2L D-Tronic Engines

Section 4 - Electrical System
- A - Starting System
- B - Charging System
- C - Glow Plug System (If Equipped)
- D - Instrumentation
- E - Wiring Diagrams

Section 5 - Fuel System
- A - Description
- B - Fuel Delivery Pump and Fuel Filter
- C - Injectors
- D - Injection Pump
- E - EDI Diagnosis

Section 6 - Cooling System
- A - Seawater Cooling System
- B - Closed Cooling System

Section 7 - Intake And Exhaust System
- A - Intercooler
- B - Intake / Exhaust Manifold, Elbows and Risers
- C - Turbocharger

Section 8 - Drive System
- A - ZF / Hurth Transmissions
- B - Propeller Shaft Models

Section 9 - Power Steering System
- A - Pump And Related Components

Important Information 1
Removal And Installation 2
Engine Mechanical 3
Electrical System 4
Fuel System 5
Cooling System 6
Intake And Exhaust System 7
Drive System 8
Power Steering System 9

APERÇU — Engine Manual — fichier complet disponible après achat 1/10

Notice

Throughout this publication, Dangers, Warnings and Cautions (accompanied by the International HAZARD Symbol ⚠) are used to alert the mechanic to special instructions concerning a particular service or operation that may be hazardous if performed incorrectly or carelessly. **OBSERVE THEM CAREFULLY!**

These Safety Alerts alone cannot eliminate the hazards that they signal. Strict compliance to these special instructions when performing the service, plus common sense operation, are major accident prevention measures.

⚠ DANGER

Immediate hazards which will result in severe personal injury or death.

⚠ WARNING

Hazards or unsafe practices which could result in severe personal injury or death.

⚠ CAUTION

Hazards or unsafe practices which could result in minor personal injury or product or property damage.

APERÇU — Engine Manual — fichier complet disponible après achat 2/10

Notice to Users of This Manual

This service manual has been written and published by the Service Department of Mercury Marine to aid our dealers' mechanics and company service personnel when servicing the products described herein.

It is assumed that these personnel are familiar with marine product servicing procedures. Furthermore, it is assumed that they have been trained in the recommended service procedures of Mercury MerCruiser product, including the use of mechanics' common hand tools and the special Mercury Marine or recommended tools from other suppliers.

We could not possibly know of and advise the marine trade of all conceivable procedures and of the possible hazards and/or results of each method. Therefore, anyone who uses a service procedure and/or tool, which is not recommended by the manufacturer, first must completely satisfy himself that neither his nor the products safety will be endangered.

All information, illustrations and specifications contained in this manual are based on the latest product information available at the time of publication. As required, revisions to this manual will be sent to all dealers contracted by us to sell and/or service these products.

We reserve the right to make changes to this manual without prior notification.

Refer to dealer service bulletins, operation maintenance and warranty manuals and installation manuals for other pertinent information concerning the products described in this manual.

It should be kept in mind, while working on the product, that the electrical system is capable of violent and damaging short circuits or severe electrical shocks. When performing any work where electrical terminals could possibly be grounded or touched by the mechanic, the battery cables should be disconnected at the battery.

Any time the intake or exhaust openings are exposed during service they should be covered to protect against accidental entrance of foreign material which could enter the cylinders and cause extensive internal damage when the engine is started.

It is important to note, during any maintenance procedure replacement fasteners must have the same measurements and strength as those removed. Numbers on the heads of the metric bolts and on the surfaces of metric nuts indicate their strength. American bolts use radial lines for this purpose, while most American nuts do not have strength markings. Mismatched or incorrect fasteners can result in damage or malfunction, or possibly personal injury. Therefore, fasteners removed should be saved for reuse in the same locations whenever possible. Where the fasteners are not satisfactory for re-use, care should be taken to select a replacement that matches the original.

Engine Mechanical Components

Many of the engine mechanical components are designed for marine applications. Unlike automotive engines, marine engines are subjected to extended periods of heavy load and wide open throttle operation and, therefore, require heavy-duty components. Special marine engine parts have design and manufacturing specifications that are required to provide long life and dependable performance. Marine engine parts also must be able to resist the corrosive action of salt or brackish water that will rust or corrode standard automotive parts within a short period of time.

Failure to use recommended Mercury / Quicksilver service replacement parts can result in poor engine performance and/or durability, rapid corrosion of parts subjected to salt water and possibly complete failure of the engine.

Replacement Parts

Use of parts other than the recommended service replacement parts, will void the warranty on those parts that are damaged as a result.

⚠ WARNING

Electrical and fuel system components on Mercury MerCruiser Engines and Stern Drives are designed and manufactured to comply with U.S. Coast Guard Rules and Regulations to minimize risks of fire or explosion.

Use of replacement electrical or fuel system components, which do not comply to these rules and regulations, could result in a fire or explosion hazard and should be avoided.

When servicing the electrical and fuel systems, it is extremely important that all components are properly installed and tightened. If not, any electrical component opening would permit sparks to ignite fuel vapors from fuel system leaks, if they existed.

APERÇU — Engine Manual — fichier complet disponible après achat 4/10

Models Covered in This Manual

Sterndrive (MCM)	Serial Number
D2.8L D-Tronic	0K000001 and Above
D4.2L D-Tronic	0K000001 and Above

Inboard (MIE)	Serial Number
D2.8L D-Tronic	0K000001 and Above
D4.2L D-Tronic	0K000001 and Above

IMPORTANT INFORMATION

Section 1A - General Information

Introduction 1A-3
How to Use This Manual 1A-3
Page Numbering 1A-3
Engine Serial Number / Decal Locations . 1A-4
Operation / Duty Cycle 1A-5
Engine Break-In 1A-6
Initial Break-In Procedure 1A-6
Mercury/Quicksilver Lubricants, Sealants And Adhesives 1A-7

IMPORTANT INFORMATION

Section 1B - Maintenance

Torque Specifications 1B-3
Special Tools 1B-3
Tools 1B-3
Lubricants / Sealants / Adhesives 1B-3
Engine Specifications 1B-4
Sterndrive (MCM) Engines 1B-4
Inboard (MIE) Engines 1B-5
Capacities 1B-6
Engines 1B-6
Drives 1B-6
Transmissions 1B-6
Maintenance Schedules 1B-7
Maintenance Intervals 1B-7
Sterndrive (MCM) Engines 1B-8
Inboard (MIE) Engines 1B-11
Engine External Views 1B-13
Starboard Side View 1B-13
Front View 1B-14
Port Side View 1B-15
Rear View 1B-16
Engine Oil 1B-17
Oil Level 1B-17
Changing Engine Oil and Oil Filter . . . 1B-19
Fuel 1B-21
Precautions 1B-21
General Information 1B-22
Diesel Fuel In Cold Weather 1B-22
Fuel Filter 1B-23
Closed Cooling System 1B-28
Coolant Requirement 1B-28
Checking Level 1B-29
Draining 1B-30
Filling 1B-32
Sacrificial Anodes 1B-33
Removal 1B-33
Inspection 1B-33
Disassembly 1B-34
Reassembly 1B-34
Installation 1B-34
Flushing Seawater System 1B-35
SternDrive (MCM) Models 1B-35
Inboard (MIE) Models 1B-36
Inspect Water Pickups 1B-38
SternDrive Gear Housing 1B-38
Inboard Though the Hull Pickup 1B-38
Lubrication 1B-39
Throttle Cable 1B-39
Shift Cable 1B-39
Engine Coupler / U-joint Shaft Splines 1B-40
U-joints 1B-41
Drive Shaft Extension Models 1B-42
Sterndrive Unit and Transom Assembly 1B-42
Continuity Circuit 1B-43
Continuity Circuit (continued) 1B-44
MerCathode 1B-45
Engine Mounts 1B-45
Electrical System 1B-45
Power Steering 1B-46
Checking Fluid Level 1B-46
Filling and Bleeding 1B-48
Transmission 1B-49
Checking Fluid Level 1B-49
Power Trim 1B-50
Checking Fluid Level 1B-50
Filling 1B-51
Gear Lube Monitor 1B-52
Checking Fluid Level 1B-52
Filling 1B-52
Seawater Strainer 1B-53
Air Filter 1B-54
Removal 1B-54
Inspection 1B-54
Cleaning 1B-55
Installation 1B-55
Drive Belts 1B-56
General Information 1B-56
Inspection 1B-57
Engine Water Circulating Pump Belt . . 1B-57
Alternator Belt 1B-58
Power Steering Pump Belt 1B-60
Vacuum Pump Belt 1B-62
Battery 1B-64
Charging System 1B-64
Corrosion and Corrosion Protection 1B-64
Saltwater Operation 1B-64
Freezing Temperature and Cold Weather Operation 1B-65
Cold Weather or Extended Storage 1B-66
Power Package Layup 1B-66
Draining 1B-67
Recommissioning 1B-73

INDEX

APERÇU — Engine Manual — fichier complet disponible après achat 6/10

IMPORTANT INFORMATION

SECTION 1C - Troubleshooting

Precautions 1C-3
Poor Boat Performance and/or Poor Maneuverability 1C-5
Improper Full Throttle Engine RPM 1C-6
RPM Too High 1C-6
RPM Too Low 1C-6
Engine Cranks Over But Will Not Start Or Starts Hard 1C-7
Electrical 1C-7
Fuel System 1C-7
Miscellaneous 1C-9
Engine Will Not Crank Over or Starter Inoperative 1C-9
Glow Plugs Inoperative 1C-10
Charging System Inoperative 1C-11
Noisy Alternator 1C-11
Engine Operates Poorly at Idle 1C-12
Engine Operates Poorly At High Rpm ... 1C-13
Poor Fuel Economy 1C-14
Engine Smoking 1C-15
Black Smoke 1C-15
Blue Smoke 1C-16
White Smoke 1C-16
Exhaust Gas Temperature 1C-17
High 1C-17
Low 1C-17
Turbocharger 1C-18
Engine Noise 1C-19
Valve Cover Area 1C-20
Cylinder Area 1C-20
Camshaft Area 1C-21
Crankshaft Area 1C-22
Miscellaneous 1C-23
Oil Pressure 1C-23
Low Oil Pressure 1C-25
High Oil Pressure 1C-25
Excessive Oil Consumption 1C-26
Water / Coolant in Engine 1C-27
Important Information 1C-27
Water / Coolant In Crankcase Oil 1C-27
Water / Coolant On Top Pistons 1C-28
Engine Overheats 1C-29
Cooling System 1C-29
Mechanical 1C-30
Power Steering 1C-31
Poor, Erratic or No Assist 1C-31
Noisy Pump 1C-32
Fluid Leaks 1C-32
Insufficient Water Flow From Belt Driven Seawater Pump 1C-33
ZF / Hurth Hydraulic Transmission 1C-34

REMOVAL AND INSTALLATION

Section 2A - Sterndrive (MCM) Models

Torque Specifications 2A-3
Special Tools 2A-3
Lubricants / Sealants / Adhesives 2A-4
Removal 2A-4
Installation 2A-7
Engine Installation / Alignment 2A-7
Engine Connections 2A-15
Throttle Cable Installation and Adjustment 2A-21
Shift Cable Installation and Adjustment 2A-23
Troubleshooting Shift Problems 2A-28
Battery Cables 2A-30

REMOVAL AND INSTALLATION

Section 2B - Inboard (MIE) Models

Torque Specifications 2B-3
Tools/Lubricants/Adhesives 2B-3
Removal 2B-4
Engine Removal 2B-4
Installation 2B-7
Engine Installation and Initial Alignment 2B-7
Engine Final Alignment 2B-11
Engine Connections 2B-18
Throttle Cable Installation and Adjustment 2B-21
Shift Cable Installation And Adjustment 2B-21
Battery Cables 2B-21

APERÇU — Engine Manual — fichier complet disponible après achat 7/10

ENGINE

Section 3A - Engine Mechanical

Identification 3A-3
Torque Specifications 3A-4
Tools 3A-6
  Special Tools 3A-6
  Special Tools (continued) 3A-7
  Snap-On Tools 3A-8
  Kent-Moore Tools 3A-8
Lubricants/Sealants/Adhesives 3A-9
Engine Specifications 3A-10
  Piston Rings 3A-10
  Cylinder Liner Diameter 3A-10
  Cylinder Liner Protrusion 3A-11
  Head Gaskets 3A-11
  Cylinder Head 3A-11
  Oil Pump 3A-12
  Camshaft 3A-12
  Valve Lifter 3A-12
  Rocker Arm 3A-13
  Valve Adjustment 3A-13
  Valve 3A-13
  Valve Seat 3A-13
  Valve Guide 3A-14
  Valve Spring 3A-14
  Crankshaft 3A-15
  Crankshaft (continued) 3A-16
  Connecting Rods 3A-17
  Connecting Rod Crank Pin Bore 3A-17
  Connecting Rod Bushings 3A-17
  Pistons 3A-17
  Flywheel 3A-17
Precautions 3A-18
General Information 3A-19
  Engine Rotation 3A-19
  Engine Firing Order 3A-19
  Late Model Cylinder Head Gasket - Torque Sequence and Specifications 3A-20
  Early Model Cylinder Head Gasket - Torque Sequence and Specifications 3A-25
  Lubrication System - All Models 3A-28
  Examples of Bearing Failures 3A-29
  Compression Testing Procedure 3A-30
Engine Cover 3A-31
  Removal 3A-31
  Cleaning 3A-31
  Inspection 3A-31
  Installation 3A-31
Valve Covers 3A-32
  Removal 3A-32
  Cleaning 3A-33
  Inspection 3A-33
  Installation 3A-34
Water Manifold 3A-37
  Exploded Views 3A-37
  Removal 3A-38
  Cleaning 3A-38
  Inspection 3A-38
  Installation 3A-39
Cylinder Heads 3A-40
  Exploded Views 3A-40
  Removal 3A-42
  Disassembly 3A-44
  Cleaning 3A-44
  Inspection 3A-45
  Repair 3A-50
  Expansion Plugs 3A-50
  Assembly 3A-52
  Installation - Using Early Model Gaskets 3A-55
  Installation - Using Late Model Gaskets 3A-62
Rocker Arm 3A-71
  Removal 3A-71
  Cleaning 3A-71
  Inspection 3A-71
  Assembly 3A-72
  Installation 3A-73
Timing Gear Cover 3A-77
  Exploded View 3A-77
  Removal 3A-78
  Cleaning 3A-78
  Inspection 3A-78
  Installation 3A-79
Oil Pump 3A-81
  Removal 3A-81
  Cleaning 3A-81
  Inspection 3A-82
  Reassembly 3A-83
  Installation 3A-83
Oil Pressure Relief Valve 3A-84
  Removal 3A-84
  Disassembly 3A-85
  Cleaning 3A-85
  Inspection 3A-86
  Assembly 3A-86
  Installation 3A-87
Oil Pan and Oil Pick-Up Tube Assembly . 3A-88
  Removal 3A-88
  Cleaning 3A-89
  Inspection 3A-89
  Installation 3A-89

INDEX

APERÇU — Engine Manual — fichier complet disponible après achat 8/10

ENGINE (continued)

Section 3A - Engine Mechanical (continued)

Adapter / Oil Thermostat 3A-91
Removal 3A-91
Disassembly 3A-92
Cleaning and Inspection 3A-92
Testing 3A-92
Installation 3A-93
Camshaft 3A-95
Exploded View 3A-95
Testing - Measuring Lobe Lift 3A-96
Removal 3A-96
Inspection 3A-98
Installation 3A-99
Camshaft Bearings 3A-100
Inspection 3A-100
Removal 3A-100
Installation 3A-101
Valve Lifters 3A-102
Removal 3A-102
Cleaning 3A-103
Inspection 3A-103
Installation 3A-104
Valve Push Rods 3A-105
Removal 3A-105
Cleaning 3A-105
Inspection 3A-105
Installation 3A-105
Connecting Rod / Piston Assembly 3A-106
Measuring Rod Bearing Clearance .. 3A-106
Removal 3A-107
Disassembly 3A-108
Cleaning 3A-109
Inspection 3A-109
Assembly 3A-113
Installation 3A-114
Rear Oil Seal 3A-116
Removal 3A-116
Installation 3A-117
Crankshaft and Main Bearings 3A-118
Removal 3A-118
Cleaning 3A-123
Inspection 3A-124
Installation 3A-127
Cylinder Liners 3A-136
Removal 3A-136
Identification 3A-137
Cleaning and Inspection 3A-138
Installation 3A-139
Flywheel Housing, Coupler / Drive Plate And Flywheel 3A-144
Exploded View 3A-144
Flywheel Housing 3A-148
Sterndrive (MCM) Coupler / Inboard (MIE) Drive Plate 3A-150
Flywheel 3A-151
Engine Mounts 3A-152
Front Mounts 3A-152
MIE (Inboard) Transmission Mounts . 3A-153
Engine 20-Hour Break-In Period 3A-154
After Break-in Period 3A-154

ELECTRICAL SYSTEMS

Section 4A - Starting System

Identification 4A-3
Specifications 4A-3
Torque Specifications 4A-3
Lubricants / Sealants / Adhesives 4A-3
Replacement Parts 4A-4
Starting System Components 4A-4
Inspection 4A-6
Periodic Inspection 4A-6
Testing Voltage 4A-6
Removal 4A-7
Starter Motor 4A-7
Solenoid Switch 4A-8
Installation 4A-9
Solenoid Switch 4A-9
Starter Motor 4A-10

ELECTRICAL SYSTEMS

Section 4B - Charging System

Identification 4B-3
Replacement Parts Warning 4B-3
Specifications 4B-4
Torque Specifications 4B-4
Special Tools 4B-5
Lubricants/Sealers/Adhesives 4B-5
Wire Color Code Abbreviations 4B-5
Precautions 4B-6
General 4B-6
Electronic Diesel Injection (EDI) Electrical System Precautions 4B-6
Battery Precautions - Multiple EDI Engines 4B-7
Charging System Components 4B-8
Inspection 4B-9
Troubleshooting Tests (Alternator on Engine) 4B-10
Circuitry Test 4B-10
Output Circuit 4B-11
Excitation Circuit 4B-12
Sensing Circuit 4B-13
Current Output Test 4B-14
Exploded View 4B-16
Removal 4B-17
Alternator 4B-17
Alternator Bracket 4B-17
Installation 4B-18
Alternator Bracket 4B-18
Alternator 4B-18
Battery Isolators 4B-19
Dual Battery Charging Systems 4B-19
Battery Isolator Diagram 4B-20

ELECTRICAL SYSTEMS

Section 4C - Glow Plug System

Identification 4C-3
Specifications 4C-3
Torque Specifications 4C-4
Lubricants / Sealants / Adhesives 4C-4
Special Tools 4C-4
Description 4C-4
Precautions 4C-4
Glow Plug Testing (Prior to Removal) 4C-5
Removal 4C-6
Cleaning 4C-7
Inspection 4C-7
Installation 4C-8
Glow Plug Actuator Relay and Auxiliary Relay 4C-9
Testing 4C-9
Removal 4C-10
Cleaning 4C-10
Inspection 4C-10
Installation 4C-10
Glow Plug Circuit Diagram 4C-11

ELECTRICAL SYSTEMS

Section 4D - Instrumentation

Identification 4D-3
Gauges 4D-3
Panels 4D-3
Special Tools 4D-4
Tools 4D-4
Lubricants / Sealants / Adhesives 4D-4
Wire Color Abbreviations 4D-4
Precautions 4D-5
General Information 4D-6
Special Information 4D-6
Tachometer 4D-6
QSI Series Gauge Lighting Options . . . 4D-7
Gauges 4D-8
Removal 4D-8
Testing 4D-8
Installation 4D-11
Senders 4D-11
Oil Pressure 4D-11
Water Temperature - Primary Station . 4D-13
Primary Station Switches 4D-15
Ignition Key Switch 4D-15
Audio Warning Test and Panel Light Switch 4D-17
Audio Warning System 4D-19
Alarm 4D-19
Oil Pressure Switch 4D-20
Water Temperature Switch / Sender . . 4D-21
Transmission Fluid Temperature Switch 4D-24
Second Station Extension Harness 4D-26
Remote Control / Neutral Start Safety Circuit 4D-29
Primary Station 4D-29
Secondary Station 4D-30

APERÇU — Engine Manual — fichier complet disponible après achat 10/10