HINSH-H10-001-1

SERVICE MANUAL

MARINE DIESEL ENGINE

6LP Series

6LP-DT(Z)E(1)
6LP-ST(Z)E(1)

2000.3.13

YANMAR

SERVICE MANUAL

MARINE DIESEL ENGINE

MODEL

6LP-DTE/-DTZE(1)
6LPA-DTP/-DTZP
6LP-STE/-STZE(1)
6LPA-STP/-STZP

YANMAR DIESEL ENGINE CO.,LTD.

Publication No.	HINSHI-H10-001-1

History of Revision

Page No.	1

Manual Name	Yanmar Service Manual for Marine Diesel Engine
Engine Model:	6LP-DTE/DTZE/DTZE1, 6LP-STE/STZE/STZE1

Number of revision	Date of revision	Reason for correction	Outline of correction	Correction item No.(page)	Corrected by
●	New edition	July 1998			
●	1st revised edition	April 1999	(Publication No. HINSHI-H10-001-1) 6LP-DTZE1, 6LP-STZE1 (less power steering oil pump) added		

APERÇU — Engine Manual — fichier complet disponible après achat

FOREWORD

This manual describes the service procedures for the 6LP series marine diesel engine.

Please use this manual for accurate, quick and safe servicing of the respective engine. Since the explanation herein assumes the standard type engine, the specifications and components may partially be different from the engine installed on each boat. Please also refer to the service manual for each boat for details.

The specifications and components are subject to change for improvement of the engine quality. If any modification of the contents described in this manual becomes necessary, it will be notified in the form of a correction notice each time.



These products have been developed, designed, and manufactured in the facilities certified by the Standards for Quality Systems of ISO 9001

The contents of this service manual may not be copied or reproduced without permission.

APERÇU — Engine Manual — fichier complet disponible après achat

CONTENTS

1. For Safe Operation 1-1
1.1 Warning Symbols 1-1
1.2 Precautions for Safe Servicing 1-2
1.3 Location for Product Safety Labels 1-6

2. General 2-1
2.1 Specifications 2-1
2.2 External Views 2-2
2.3 Piping Diagram 2-4
2.4 Performance Curves 2-6
2.5 Front Power Take-Off (PTO) Output 2-8
2.6 Fuel Oil 2-10
2.7 Lube Oil 2-11
2.8 Cooling Water 2-11
2.9 Location of Senders and Warning Switches 2-12

3. Engine Overhaul 3-1
3.1 Cylinder Head 3-1
3.1.1 Components 3-1
3.1.2 Removal of Cylinder Head 3-4
3.1.2.1 Drain the engine cooling water 3-4
3.1.2.2 Remove the turbocharger 3-4
3.1.2.3 Remove the fresh water tank. 3-4
3.1.2.4 Remove the fuel filter. 3-4
3.1.2.5 Remove the intake manifold and intercooler. 3-4
3.1.2.6 Remove the fuel injection pipe and fuel injection nozzle (For 6LP-DTE series) 3-4
3.1.2.7 Remove the bonnet. 3-5
3.1.2.8 Remove the semi-circular plug 3-5
3.1.2.9 Remove the timing belt and pulley 3-5
3.1.2.10 Remove the camshaft oil seal retainer 3-5
3.1.2.11 Remove the fuel injection nozzle (6LP-STE series) 3-5
3.1.2.12 Remove the camshaft (6LP-STE series) 3-5
3.1.2.13 Remove the cylinder head assy 3-5

APERÇU — Engine Manual — fichier complet disponible après achat

3.1.3 Disassembly of Cylinder Head 3-7
3.1.3.1 Remove the valve lifter and shim (6LP-DTE series only) 3-7
3.1.3.2 Remove the valve bridge (6LP-STE series only) 3-7
3.1.3.3 Remove the intake and exhaust valves 3-7
3.1.4 Inspection and Servicing of Cylinder Head Components 3-7
3.1.4.1 Clean the piston and cylinder block top surfaces 3-7
3.1.4.2 Clean the cylinder head 3-8
3.1.4.3 Inspect the cylinder head 3-9
3.1.4.4 Clean the intake and exhaust valves 3-9
3.1.4.5 Inspection of valve stem and valve guide 3-9
3.1.4.6 Inspect and lap the intake and exhaust valves 3-10
3.1.4.7 Inspect and clean the valve seat 3-11
3.1.4.8 Check the valve spring 3-12
3.1.4.9 Check the valve rocker arm and shaft (For 6LP-STE series only) 3-13
3.1.4.10 Check the camshaft and bearing 3-14
3.1.5 Replacement of Oil Seal for Camshaft 3-16
3.1.6 Assembly of Cylinder Head 3-17
3.1.6.1 Install the intake and exhaust valves 3-17
3.1.6.2 Install the valve bridge (6LP-STE series) 3-18
3.1.6.3 Install the valve lifter and shim (6LP-DTE series only) 3-18
3.1.7 Installation of Cylinder Head 3-19
3.1.7.1 Measure protrusion of piston head for top surface of cylinder block to determine an appropriate cylinder head gasket 3-19
3.1.7.2 Set cylinder No.1 at the bottom dead center 3-20
3.1.7.3 Install the cylinder head 3-21
3.1.7.4 Install the camshaft 3-22
3.1.7.5 Install the fuel injection nozzle 3-23
3.1.7.6 Install the camshaft oil seal retainer 3-23
3.1.7.7 Install the pulley and timing belt 3-24
3.1.7.8 Check and adjust the valve clearance 3-24
3.1.7.9 Install the semi-circular plug 3-24
3.1.7.10 Install the bonnet 3-24
3.2 Cylinder Block 3-25
3.2.1 Components 3-25
3.2.2 Preparation for Disassembly 3-26
3.2.2.1 Remove the flywheel 3-26
3.2.2.2 Install the engine on the engine stand for disassembling it 3-26
3.2.2.3 Remove the timing belt and pulley 3-26

APERÇU — Engine Manual — fichier complet disponible après achat

3.2.2.4 Remove the cylinder head 3-26
3.2.2.5 Remove the fresh water pump and sea water pump 3-26
3.2.2.6 Remove the alternator 3-26
3.2.2.7 Remove the timing gear 3-26
3.2.2.8 Remove the fuel injection pump 3-26
3.2.2.9 Remove the oil pan and timing gear case 3-26
3.2.2.10 Remove the oil cooler 3-26
3.2.2.11 Remove the engine mount 3-26
3.2.3 Disassembly of Cylinder Block 3-27
3.2.3.1 Remove the rear oil seal case 3-27
3.2.3.2 Check the connecting rod thrust clearance 3-27
3.2.3.3 Remove the connecting rod cap and check oil clearance 3-27
3.2.3.4 Remove the piston and connecting rod assembly 3-29
3.2.3.5 Inspect the thrust clearance of the crankshaft 3-29
3.2.3.6 Remove the main bearing cap and inspect the oil clearance 3-29
3.2.3.7 Remove the crankshaft 3-32
3.2.3.8 Remove the check valve and oil nozzle (for piston cooling) 3-32
3.2.4 Inspection of Cylinder Block 3-32
3.2.4.1 Clean the cylinder block 3-32
3.2.4.2 Measure warpage of the top surface of cylinder block 3-32
3.2.4.3 Visually check scratches of the cylinder in the vertical direction 3-32
3.2.4.4 Measure the cylinder bore diameter 3-32
3.2.4.5 Clean the cylinder ridge 3-33
3.2.4.6 Inspect the main bearing cap bolt 3-33
3.2.5 Disassembly of Piston and Connecting Rod 3-34
3.2.5.1 Check fitting between the piston and piston pin 3-34
3.2.5.2 Remove the piston ring 3-34
3.2.5.3 Remove the connecting rod from the piston 3-34
3.2.6 Inspection of Piston and Connecting Rod 3-35
3.2.6.1 Clean the piston 3-35
3.2.6.2 Inspect the piston and piston ring 3-35
3.2.6.3 Inspect the piston pin fit 3-37
3.2.6.4 Inspect the connecting rod 3-37
3.2.7 Inspection and Servicing of Crankshaft 3-39
3.2.7.1 Measure circle runout of the crankshaft 3-39
3.2.7.2 Inspect the crank journal and crank pin 3-39
3.2.8 Replacement of Oil Seal for Crankshaft 3-40
3.2.8.1 When the rear oil seal case has been removed from the cylinder block 3-40
3.2.8.2 When the rear oil seal case is installed to the cylinder block 3-40
3.2.9 Assembly of Piston and Connecting Rod 3-40
3.2.9.1 Assemble the piston and connecting rod 3-40
3.2.9.2 Install the piston ring 3-41
3.2.9.3 Install the crank pin bearing 3-42

APERÇU — Engine Manual — fichier complet disponible après achat

3.2.10 Assembly of Cylinder Block 3-42
3.2.10.1 Install the oil nozzle and check valve for the piston cooling 3-42
3.2.10.2 Install the main bearing 3-42
3.2.10.3 Place the crankshaft on the cylinder block 3-43
3.2.10.4 Install the thrust bearing 3-43
3.2.10.5 Install the main bearing cap 3-43
3.2.10.6 Inspect the thrust clearance of the crankshaft 3-44
3.2.10.7 Install the piston and connecting rod assembly 3-44
3.2.10.8 Install the connecting rod cap 3-45
3.2.10.9 Check the connecting rod thrust clearance 3-45
3.2.10.10 Install the rear oil seal case 3-46
3.2.11 Next Assembly 3-47
3.2.11.1 Install the engine mounting bracket 3-47
3.2.11.2 Install the timing gear case 3-47
3.2.11.3 Install the oil pan 3-47
3.2.11.4 Install the rear end plate 3-47
3.2.11.5 Install the flywheel 3-47
3.2.11.6 Install the flywheel housing by tightening the set bolts 3-47
3.2.11.7 Upside down the engine and place it on the engine stand 3-47
3.2.11.8 Install the thermostat 3-47
3.2.11.9 Install the alternator and bracket assembly 3-47
3.2.11.10 Install the fresh water pump 3-47
3.2.11.11 Install the cylider head 3-47
3.2.11.12 Install the timing belt and pulley 3-47
3.2.11.13 Remove the engine from the engine stand 3-47
3.2.11.14 Install the turbocharger oil pipe 3-47
3.2.11.15 Install the oil cooler assembly, oil dipstick and guide 3-47
3.2.11.16 Install the sender units and warning switches 3-47
3.2.11.17 Install the fuel injection pump 3-47
3.2.11.18 Install the sea water pump 3-47
3.2.11.19 Install the lube oil filter 3-47
3.3 Timing Belt 3-48
3.3.1 Components 3-48
3.3.2 Removal of Timing Belt 3-49
3.3.2.1 Remove the timing belt cover 3-49
3.3.2.2 Set the No.1 cylinder at the bottom dead center (BDC) 3-49
3.3.2.3 Remove the timing belt 3-49
3.3.2.4 Remove the idler pulley 3-50
3.3.2.5 Remove No.2 camshaft timing pulley 3-50
3.3.2.6 Remove the bonnet 3-50
3.3.2.7 Remove No.1 camshaft timing pulley 3-50
3.3.3 Checking of Timing Belt 3-50
3.3.3.1 Checking the timing belt 3-50
3.3.3.2 Inspect the idler pulley 3-52
3.3.3.3 Inspect the tension spring and tensioner 3-52

APERÇU — Engine Manual — fichier complet disponible après achat

3.3.4 Installation of Timing Belt 3-53
3.3.4.1 Install No.1 camshaft timing pulley 3-53
3.3.4.2 Install the bonnet 3-53
3.3.4.3 Install No.2 camshaft timing pulley 3-53
3.3.4.4 Install the idler pulley 3-54
3.3.4.5 Set the No.1 cylinder to the bottom dead center (BDC) 3-54
3.3.4.6 Install the timing belt 3-54
3.3.4.7 Install the tension spring (6LP-DTE series) 3-55
3.3.4.8 Install the timing belt tensioner (6LP-STE series) 3-55
3.3.4.9 Inspect the valve timing 3-55
3.3.4.10 Install the timing belt cover 3-56

3.4 Timing Gear 3-57

3.4.1 Components 3-57

3.4.2 Removal of Timing Gear 3-58
3.4.2.1 Remove the V-belt for driving the fresh water pump and alternator 3-58
3.4.2.2 Loosen the crankshaft pulley 3-58
3.4.2.3 Remove the timing belt and pulley 3-58
3.4.2.4 Remove the camshaft oil seal retainer 3-58
3.4.2.5 Remove the crankshaft pulley 3-58
3.4.2.6 Remove the alternator adjusting bar 3-58
3.4.2.7 Remove the timing gear cover 3-58
3.4.2.8 Remove the oil pump drive shaft gear 3-58
3.4.2.9 Inspect thrust clearance of the idler gear 3-59
3.4.2.10 Remove the idler gear 3-59
3.4.2.11 Remove the fuel injection pump drive gear 3-59
3.4.2.12 Remove the crankshaft timing gear 3-59

3.4.3 Inspection of Timing Gear 3-60
3.4.2.1 Check the idler gear 3-60
3.4.3.2 Check the fuel injection pump drive gear bearing 3-60
3.4.3.3 Replace the fuel injection pump drive gear bearing, as needed 3-60
3.4.3.4 Inspect backlash of the timing gear 3-61

3.4.4 Replacement of Crankshaft Front Oil Seal 3-61
3.4.4.1 Replace the crankshaft front oil seal 3-61

3.4.5 Replacement of Fuel Injection Pump Drive Gear Oil Seal 3-62
3.4.5.1 Replace the fuel injection pump drive gear oil seal 3-62

3.4.6 Installation of Timing Gear 3-63
3.4.6.1 Install the crankshaft timing gear 3-63
3.4.6.2 Install the fuel injection pump drive gear 3-63
3.4.6.3 Install the idler gear 3-63
3.4.6.4 Install the oil pump drive shaft gear 3-64
3.4.6.5 Install the timing gear cover 3-64
3.4.6.6 Install the alternator adjusting bar 3-64
3.4.6.7 Install the crankshaft pulley 3-65

APERÇU — Engine Manual — fichier complet disponible après achat

3.4.6.8 Install camshaft oil seal retainer 3-65
3.4.6.9 Install timing pulleys and timing belt 3-65
3.4.6.10 Tighten crankshaft pulley bolt 3-65
3.4.6.11 Install the V-belt for driving the fresh water pump and alternator 3-65

3.5 Valve Clearance Inspection and Adjustment 3-66

3.5.1 Inspection of Valve Clearance 3-66
3.5.1.1 Remove the bonnet 3-66
3.5.1.2 Set No.1 cylinder to the top dead center (TDC) 3-66
3.5.1.3 Inspect the valve clearance 3-66

3.5.2 Adjustment of Valve Clearance 3-67
3.5.2.1 Adjust the valve clearance 3-67
3.5.2.2 Install the bonnet 3-68

3.6 Inspection and Adjustment of Injection Timing 3-69

3.6.1 Inspection of Injection Timing 3-69
3.6.1.1 Set the No.1 or No.6 cylinder at the top dead center (TDC) /compression 3-69
3.6.1.2 Install the plunger stroke measuring tool and dial indicator 3-69
3.6.1.3 Inspect the injection timing 3-69

3.6.2 Adjustment of Injection Timing 3-70
3.6.2.1 Adjust the injection timing 3-70
3.6.2.2 Tighten union nuts for the fuel injection pipe 3-70
3.6.2.3 Start the engine and check for fuel oil leakage 3-70

3.7 Service Specifications 3-71

3.7.1 Engine Adjusting Standards 3-71

3.7.2 Service Standards 3-72

3.7.3 Nut and Bolt Tightening Torque 3-75

3.8 Turbocharger 3-76

3.8.1 Construction and Function 3-76
3.8.1.1 Overview of construction and function 3-76
3.8.1.1.1 Turbine 3-76
3.8.1.1.2 Blower 3-76
3.8.1.1.3 Bearing 3-76
3.8.1.1.4 Sealing structure at blower side 3-76

3.8.2 Components (RHE6W Turbocharger) 3-78

3.8.3 Service Specifications 3-79
3.8.3.1 Service standards 3-79
3.8.3.2 Nut and bolt tightening torque 3-80

3.8.4 Periodic Inspection Procedure 3-81
3.8.4.1 Periodic inspection intervals 3-81
3.8.4.2 Inspection procedure 3-81
3.8.4.2.1 Running of turbine shaft 3-81
3.8.4.2.2 Inspection of turbine shaft play 3-82

APERÇU — Engine Manual — fichier complet disponible après achat